

## AMBIENT TEMPERATURE MONITORING


With an ambient temperature probe, the incubator is able to compare the gap between ambient and setting temperature and changing heating power output accordingly in order to provide a more stable inside hood air temperature.

#### | PID FUZZY ALGORITHM

With the help of the latest PID technology, the minimizes the temperature variability to an unprecedented 0.2 and temperature overshoot is also reduced dramatically.

# HEATING SYSTEM MONITORING

It monitors not only hood air temperature but also a radiator and circuit air temperature. By collecting each parts' temperature information, Its temperature control system is much more accurate and safe than others.



#### **TEMPERATURE UNIFORMITY**

The incubator's air circuit system is designed based on massive experimentation. With plenty aerodynamics knowledge, the temperature uniformity is improved as Bmuch as possible in order to give infants the safest micro-environment.





### HEATING SOURCE DOUBLE PROTECTION

It is equipped with both a thermocouple and mechanical temperature switch to protect the heating source of the heating system and evaporator. Thermocouple reads real-time temperature and limits the temperature in a safe range by feedback the temperature value to the control module. While mechanical temperature switch is in series circuits, if the heating source temperature goes unmoral level, the temperature switch cuts off the circuit physically.



# THREE CHANNEL TEMPERATURE SENSORS

There are three channel of temperature sensors in the module box. One channel is for reading hood temperature to remain the temperature at setting value. Another temperature sensor is in an individual circuit for protection only. The third sensor is used to compare the reading with other two sensors. If the reading of the three sensors differs from 0.8°C, the alarm is triggered.



**BACKUP BATTERY** 

It is equipped with a backup battery, once the power supply is off, the backup battery supports the air circuit and the alarm system keep working for at least 30 minutes

#### **IALARM LIST**

It provides a wide range of physiological and technical alarms in order to improve the treatment effect and eliminate residual risk from the device.

#### **A** System Fault Alarm

Stuck Key	This alarm occurs when a stuck key is detected.	
Sensor Disconnect	This alarm occurs when communication with the sensor module fails.	
Sensor Module Failure3	This alarm occurs when the controller detects a sensor module fan is not rotating.	
Sensor Module Failure6	This alarm occurs when the controller detects the ambient temperature sensor is open or shorted.	
Sensor Module Failure8	This alarm occurs when the controller detects that the sensor module watchdog reset.	
Low Air Flow	This alarm occurs when an air circulation failure is detected.	
Air Flow Probe Failed	This alarm occurs if the airflow probe connection is open or short-circuited.	
Motor Failed	This alarm is activated when the fan motor speed falls outside specified tolerances.	
Power Failure	This alarm occurs when the AC power supply is off.(within the 30s)	
Battery Disconnect	This Alarm occurs when the battery is disconnected.	
Sensor Out of Position	This alarm occurs when the sensor module is not in the hood.	
Access Panel Open	This alarm occurs when the access panel is open.	
Heater Failed1	This alarm occurs when the heater is over temperature.	
Heater Failed2	This alarm occurs when the heater is damaged.	
Air Probe Failed	This alarm occurs when one of the two thermistors in the sensor module differ from the other by 0.8°C or both two thermistors have a measurement error exceeding acceptable limits.	
Skin1 Probe Fail Alarm	This alarm occurs in the Skin mode if the Skin1 probe is electrically open or shorted.	
Watchdog Failed	This alarm occurs when a failure is detected with the watchdog.	

#### **3** Temperature Alarm

High Skin Temperature	This alarm occurs when the indicated displayed temperature differs from the set temperature by >0.5°C or >1.0°C (user selectable, default 1.0°C).
Low Skin Temperature	This alarm occurs when the indicated displayed temperature differs from the set temperature by $<0.5^{\circ}\text{C}$ or $<1.0^{\circ}\text{C}$ (user selectable, default 1.0°C).
Remove Skin2 Probe	This alarm occurs when two skin probes are installed and the Skin mode is selected.
Skin Probe Disconnect	This alarm is activated when the Skinl temperature probe (only in the Skin mode) is removed from the sensor module. The associated monitoring display is blanked. (within 30s)
High Temp CutOut	Under air control, this alarm is activated if the displayed incubator temperature reaches 38°C for set temperatures <37°C, or 40°C for set temperatures >37°C. Under skin control, this alarm is activated if the incubator temperature reaches 40°C for any set temperature.
High Air Temperature	This alarm occurs when the indicated displayed temperature differs from the set temperature by >1.5°C.
Low Air Temperature	This alarm occurs when the indicated displayed temperature differs from the set temperature by $^{\rm <2.5^{\circ}C.}$
High Skin1 Temperature	This alarm occurs when the Air mode is enabled and the infant skin temperature (from the Skinl probe) is >38.0°C when the Override mode is not active, or >39.0°C when the >37°C mode of operation is active.
High Skin 2 Temperature	This alarm occurs when the Air mode is enabled and the infant skin temperature (from the Skin2 probe) is >38.0°C when the Override mode is not active, or >39.0°C when the >37°C mode of operation is active.

### Humidity Alarm

Humidity Heater Failed 1	This alarm occurs when the humidity heater temperature is overheated.
Add Water	Not enough water in the water reservoir.
Low Humidity	This alarm occurs when the humidity is 10% lower than setting humidity.  Note: The alarm is blocked for 30 minutes every time turn on the machine, or 15 minutes every time the humidity setting value is changed.
Reservoir Out of Position	This alarm occurs when the water reservoir not in position.
Humidity Heater Failed 2	This alarm occurs when the heater thermocouple wires are open or shorted.

#### Oxygen Alarm

Oxygen Cell	This alarm occurs when the oxygen cell readings differ by more than 3%. As a result, the oxygen flow into the system is interrupted.
Difference	This alarm occurs when the displayed oxygen value is >3% below the oxygen set point.
Low Oxygen	This alarm occurs when the displayed oxygen value is >3% above the oxygen set point.
High Oxygen	This Alarm occurs when the oxygen cells are out of date.
Change Oxygen Cells	This Alarm occurs when the O2 source pressure is low or high.
Check O2 Supply	This Alarm occurs when proportional value is failed.
Servo O2 System Fail	This Alarm occurs when the oxygen cell is disconnected with module box.











### **COMFORTABLE**

- It provides newborn a supper quiet environment. With the help of aerodynamics, It's hood sound is reduced to 45cB.
- With great detail design, It is also devoted to provide medical personnel pleasure operation experience.







#### SPECIFICATION

Physical Attributes	Height 126.1cm to 146.1cm	Width 99.7cm	Depth 57.7cm	Weigh 80kg	
Hood Specifications	Tubing access ports	Access door siz	T. (2.5)	hood height Scm	
	Soft bed mattress six 73.6 x 38.6 x 1.8cm	ze Mattress tilt ±12 *		Drawer depth 36cm	
	Drawer size 28.0 x 24.7cm 28.0 x 1				
Temperature Control Modes	Temperature control modes Skin and air temperatur control mode	Air mode control temperature range 20° C-37° C	tempera	ontrol override ature range °C-39°C	
	Air mode control accuracy <±1.0°C	Skin mode control temperature range 34° C-37° C	e temper	control overrid ature range 7°C-38°C	
	Skin temperature accuracy ±0.3°C	Dual-skin temperatu monitoring Yes	ire		
Servo Humidity Option	Humidity control range 30%-95% RH	Humidity control ope time without refil 24 hours	ling reser	idity control voir capacity 1500ml	
	Humidity display a		control accuracy	У	

		r flow velocity	Temperature rise time at 22 °C (72 °F) ambient	Temperature variability
		< 10 cm/sec	<20min  From 22 °C, 50% RH,	to 35 °C) < 0.2 °C
Performance	1	Temperature overshoot	Temperature uniformity with a level mattress	Operating noise level in hood
		< 0.5 °C maximum	<08℃	≤45dBa
	Carl	bon Dioxide (CC <0.5%	02) Level	
Servo Oxygen Option		display accurac	cy Oxygen control accuracy (100% calibration)	Oxygencontrol accuracy (21% calibration)
		± 296	± 3%	±5%
	Охуд	en control range	e Oxygen display resolut	ion
		21 % to 65%	1%	
Scale Option		Weight range	Weight display resolution	on Weight accuracy
		300 g to 8 kg	1 g	±10g
Operating Environment		Temperature	Humidity	Air Velocity
		20° to 30° C	10 to 95% RH	Up to 0.3 m/sec
Storage/Shipping		Temperature	Humidity	
		-25° to 60° C	0 to 95% RH	

### VNG MEDICAL INNOVATION SYSTEM PVT.LTD.